KitchenAid®

CABINET PARTS

REFRIGERATOR

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2323158	Use & Care Guide
	2303906	Service Sheet
	2303911	Service Sheet
	2318510	Installation Instructions
	2326270	Energy Guide
	2220407	Modular Icemaker Service Sheet
2		Front Roller Asm
	2306950	Left Side
	2306951	Right Side
3	2223263	Strap, Roller
4	2306949	Roller, Rear (2)
5	2223388	Clip, Retainer (4)
6	2155013	Clip, Grille
7	488500	Screw
8	2223545	Shim
9		Hinge Top, RC
	2307008W	White
	2307008T	Biscuit
	2307008B	Black
	2307008AP	Apollo Gray
10	3400113	Screw
11	3400243	Screw
12	2307179	Hinge Assembly, Bottom−RC (Includes #20)
13		Filler, Wrapper
	2223893W	White
	2223893T	Biscuit
	2223893B	Black
	2223893AP	Apollo Gray
14		Grille
	2322234W	White
	2322234T	Biscuit
	2322234B	Black
	2322234AP	Apollo Gray
15	3400108	Screw
16		Hinge, Top FC
	2307007W	White
	2307007T	Biscuit
	2307007B	Black
	2307007AP	Apollo Gray
17	489464	Screw
18	2304888	Drain Fitting
19	2254566	Tube, Extension
20	2307049	Door Closer, RC
21	2223409	Cover, Unit
22	2223387	Pin, Roller (4)
23	549193	Clamp, Service Cord
24	489084	Screw
25	2307152	Hinge Assembly, Bottom−FC (Includes #29)
26		Button, Water Filter
	2260503W	White
	2260503T	Biscuit
	2260503B	Black
	2260503AP	Apollo Gray
27	2260526	Housing, Water Filter
28	4396841	Water Filter
29	2307051	Door Closer, FC
30		Cap, Water Filter
	2260518W	White
	2260518T	Biscuit
	2260518B	Black
	2260518AP	Apollo Gray
31		Cabinet (Not A Serviceable Part)
32	489483	Screw
35	3400858	Screw
36	2304709	Tube, Filter Outlet
37	2319868	Tube, Filter Inlet

REFRIGERATOR LINER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2224121	Escutcheon, Meat Pan Control
3	2224123	Slide Meat Pan Control
6	1118894	Switch, Rocker Arm
7	2188820	Thermistor
8	3400893	Screw
9	2319866	Ladder, Shelf (2)
10	2301234	Housing, Door Control
11	489084	Screw
12	2301235	Slide, Door Control
13	2171846	Release Valve
14	2209204	Clip, Thermistor
15	2179404K	Rack, Wine & Egg
16	1116793	Cover, Thermistor
17	489478	Screw
18	2304597	Gasket, Air Baffle
19	2223403	Cover, Air Baffle
20	2224076	Air Diffuser Assembly
21	2220377	Air Baffle
22	2162085	Socket
23	2307107	Reservoir
24	2205813	Strap
25	2255743	Light Bulb
26	2223663	Light Lens
27	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2224061	Shelf Assembly, Cantilever (2)
2	2301025	Button, Humidity
3	2301026	Slide, Humidity
4	2301117	Gasket, Side (2)
5	2203027	Cover, Meat Pan (Includes Items 13, 14, 15 & 20)
6	2301023	Snack Pan (Includes 30 & 31)
7		Glide Assembly, Crisper Pan
	2301548	Right Side
	2301549	Left Side
8	2301001	Window, Crisper Pan
9	2301567	Cover, Crisper (Includes 2, 3, 4, 11, 12, 13, 14 & 19)
10	2301027	Glass, Cover
11	2301116	Gasket (Front)
12	2301115	Gasket (Rear)
13	2174478	Eyelet, Roller
14	2188212	Roller
15	489211	Screw
16	2301031	Crisper Pan (Includes 8, 13 14, 19 & 31)
17	2223790	Meat Pan (Includes 13, 14, 19 & 22)
18		Glide Assembly, Snack Pan
	2301550	Right Side
	2301551	Left Side
19	489261	Screw
20	2223487	Deflector
21		Support Assembly
	2301569	Right Side
	2301570	Left Side
22	2203031	Handle
23	2216624	Egg Bin Assembly
25	2196485	Stud Assembly
26	2301566	Shelf, Snack Pan
27	3400894	Screw
28	2196483	Stud Assembly
29	8281158	Screw
30	2301006	Window, Snack Pan
31		Cap, Snack Pan
	2301016	Right Side
	2301017	Left Side

FREEZER LINER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	2223777	Spacer, Slide (2)
3	2223782	Basket, Front
4	2196483	Stud Assembly
5	2254611	Basket, Deep (2)
6	8281158	Screw
7	2223500	Shelf Assembly, Cantilever (2)
8	2224053	Front, Basket
9		Shelf Track
	2223787	Right Side
	2223788	Left Side
10	2254615	Shelf, Fixed
11	2254612	Basket, Lower
12	842534	Clip, Air Duct
13		Glide Assembly, Basket (2)
	2301544	Right Side
	2301545	Left Side
14	2259487	Cover, Emitter
15	8534064	Screw
16	2198635	Spring
17	2198634	Pin
18	2198665	Tube, P.C. Board
19	1115373	Switch, Rocker Arm
20	2220398	P.C. Board Emitter
21	2224125	Cover, Ice Maker
22		Slide, Ice Maker Mounting
	2212321	Right Side
	2306900	Left Side
23	489478	Screw
24	489214	Screw
25	2162085	Light Socket
26	2255743	Light Bulb
27	8281185	Screw
28	2198633	Flipper
29	2255561	Cover, Receiver
30	2301340	Slide, Ice Maker Shut Off
31	2255114	P.C. Board, Receiver
32	2198643	Lens
33	2198589	Light Shield
34	2212340	Light Lens
35	2198641	Bracket, Ice Maker Cover
36	2155597	Socket, Light
37	3400893	Screw
38		Ladder
	2320024	Left Side
	2320025	Right Side
39	2303378	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2305416	Ice Bin
2	2305294	Crusher Bin
3	2320327	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (4)
6	2305244	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
20	2305441	Latch, Bin
21	2198608	Spring, Latch
22	2187813	Wire Assembly, IDI Motor
23	8281163	Screw
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
28	2305382	Rubber Boot
29	2198607	Spring
30	2305243	Drive Shaft
31	2252130	Dispenser, Motor
32	2305208	Bracket, Motor
33	2212365	Sleeve, Coupling
100	W10127745	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #7)
	2307199W	White
	2307199T	Biscuit
	2307199B	Black
	2307199SAP	Monochromatic Stainless
	2307199S	Stainless Steel
2	2203087K	Trim, Shelf
3	2255421	Dairy Door
4	2223883	Caddy, Can
6	2219698	Stud, Handle
7		Door Gasket, Magnetic
	2223841	Mist Beige
	2223911	Black
	2326342	Apollo Grey
8		Handle
	2319727W	White
	2319727T	Biscuit
	2319727B	Black
	2319727S	Stainless Steel
9		Set Screw
	W10010140	Chrome
	W10010150	Black
10	2223879	Dairy Compartment
11	488208	Screw
12	2307048	Door Closer, Upper Cam
13	2308050	Thimble, Top
14	489420	Screw
15		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black
16	2223860	Door Bin (3)
17	3400012	Screw
18	2224173	Door Bin, Shallow
19		Nameplate
	W10046670	White
	W10046700	Biscuit
	W10046640	Black
	W10046610	Gray
20	2156006K	Plug, Trim

FREEZER DOOR PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FREEZER DOOR PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2326211W	White
	2326211T	Biscuit
	2326211B	Black
	2326211SAP	Monochromatic Stainless
	2326211SB	Stainless Steel
2		Handle
	2319727W	White
	2319727T	Biscuit
	2319727B	Black
	2319727S	Stainless Steel
3	2219698	Stud, Handle
4	488208	Screw
5	3400012	Screw
6		Set Screw
	W10010140	Chrome
	W10010150	Black
7	2304925K	Shelf Bin (3)
8		Door Gasket, Magnetic
	2223850	Mist Beige
	2223912	Black
	2326343	Apollo Grey
9	2304895	Safety Barrier
10	2308050	Thimble, Top
11	2307050	Door Closer, Upper Cam
12	489420	Screw
13		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black

FOLLOWING PARTS NOT ILLUSTRATED

	2310224	Wire Harness, Freezer Door
	2317707	Tube, Door

DISPENSER FRONT PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
3	2305202	Bracket, Motor
4	2305242	Connector, Door Bracket
5	2305262	Motor, Ice Door
6	2305258	Door, Ice
7	2305204	Support, Ice Door
8	4449745	Screw
9		Tray Assembly
	2315109W	White
	2315109T	Biscuit
	2315109B	Black
	2315109US	Universal Silver
10	2305236	Spigot
11	2305456	Separator Assembly
12	2303843	Electronic Control (Core)
13	2321746	Cover, Electronic Control
16		Pad, Water
	2305307CE	For White Model
	2305307MN	For Biscuit Model
	2305307GE	For Black Model
	2305307AS	For Monochromatic Stainless Model
	2305307GE	For Stainless Steel Model
17		Pad, Ice
	2305306CE	For White Model
	2305306MN	For Biscuit Model
	2305306GE	For Black Model
	2305306AS	For Monochromatic Stainless Model
	2305306GE	For Stainless Steel Model
18	2305287	Lens, Front Cover
20	2305342	LED Assembly
21		Front Cover, Housing (Not Available, Order #23)
23		Front Cover Assembly (Includes Items 13, 16, 17, 18, 20 & 21)
	2326256W	White
	2326256T	Biscuit
	2326256B	Black
	2326256US	Universal Silver
24	2187814	Wire Assembly, User Interface
25	2305447	Clip, Wiring

AIR FLOW PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2223733	Retainer, Fan Motor
3	2223298	Air Scoop
4	2223303	Air Duct, Upper
5	2223771	Air Duct Freezer
6	2319914	Bi−Metal, Defrost
7	2259385	Fan Motor
8	2169142	Fan Blade
9	2304241	Gasket, Evaporator Cover (2)
10	2223986	Fan Grommet (2)
11	2310236	Harness, Fan Evaporator, And Heater, Bi−Metal
12	2155789	Gasket, Fan Scroll
13	2203876	Gasket
14	2223413	Cover, Evaporator (Includes #9)
15	8281159	Screw
16	489478	Screw
17	2223395	Support, R.S
18	2203596	Support, L.S

CONTROL PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	2318985	Control Box (Includes #3)
2	2223882	Heat Shield Asm (Includes #5)
3	2307037	Control Board Asm
4	2223506	Light Lens, Control Box
5	2223857	Light Socket
6	2326255	Light Bulb

UNIT PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01

(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	777070	Screw
2	2225834	Fan, Blade
3	2223315	Condenser Assembly
4	8281197	Screw
5	3400524	Screw (6)
6	2223703	Housing, Control Board
7	2223351	Tube Suction
8	2161302	Sleeve
9	2319835	Grommet, Condenser (4)
10	2301979	Plate, Mounting
11	8281196	Screw
12	2215676	Cover, Terminal
13	2169104	Insulation, Sound
14	2305373	Clamp, Cable
15	488649	Screw
18	2223353	Tube, Condenser to Heat Loop
19	2307028	Electronic Control
20	2306932	Baseplate
22	2188823	Evaporator
23	2161324	Clamp
24	2188729	Fan, Motor
25	2223398	Tray, Evaporator
26	2224022	Heat Shield
27	2319825	Drier
28	2223801	Compressor (Includes Items 12 & 39)
29	2223800	Spacer (5)
31	2310122	Harness, Main Control
32	2224024	Fan, Motor Bracket
33	2210737	Heater, Defrost
34	2304287	Clip
36	2304175	Inverter Box
37	489373	Screw
38	2223352	Tube, Discharge
39		Grommet (4)
	2183042	Production
	4387558	Service
40	2223394	Extension, Air Baffle
41	2155547	Clip, Heat Shield
42	2310121	Unit Harness
43	2300868	Connector, Water Tube

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

6.00 oz.
(R−134A)

ICEMAKER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting, Water Tube
3	628379	Clip, Fuse
4	2313394	Shield, Water Valve
5	489478	Screw
6	2319734	Smart Valve Asm
7	2305274	Tube Clip
8	2174358	Cover
9	488649	Screw
10	628228	Mold & Heater Assembly (Also Order 542638)
11	628356	Cup, Water Fill
12	627843	Ejector
13	2198598	Ice Striper
14	2194712	Support
15	2315522	Retainer, Thermostat
16	627985	Thermostat (Also Order 542369 Cement Alumilastic)
17	8533917	Screw
18	489276	Screw
19	2187467	Harness, Wiring
20	2303583	Bracket, Icemaker Mounting
21	626684	Module Assembly (Includes Items 22 & 23)
22	626691	Motor
23	489136	Screw
100	2198597	Icemaker Assembly

OPTIONAL PARTS (NOT INCLUDED)

For Models: KSCS23FTWH01, KSCS23FTBT01, KSCS23FTBL01, KSCS23FTMS01, KSCS23FTSS01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION

PAINT, PRESSURIZED SPRAY (12 oz.)

*350942	Primer, White
*350939	Black
*350930	White
*8171357	Graphite
*4392901	Biscuit

PAINT, TOUCH−UP (1/2oz.)

72017	White
80051	Graphite
72032	Black
4392899	Biscuit
W10134625	Apollo Grey

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

PAINT, BULK (1 qt.)

799340	Black
799344	White
8171358	Graphite
4392900	Biscuit

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
799833	Kit, Evaporator Repair (Aluminum Epoxy)
833938	Kit, Terminal Connector

TORX SCREW WRENCH

1117510	Torx Key

ACCESSORIES

8201806	Previous Architect Series Handle Kit Stainless Steel